

Provision Devices

4 Channel Provision DVR



The 4 Channel device uses just the HD camera connector to communicate with Samsara.

8 Channel Provision DVR





HDMI to AHD Adapter



Samsara HD Camera Connector



The 8-channel device uses an HDMI to AHD adapter then plugs into the HD camera connector to communicate with Samsara.

If you have to Login to the 8-channel DVR the credentials are

Username – admin

Password – doesitall

Login Procedure

1. You need a cell phone or tablet
2. Go to setting and search WIFI
3. You will be looking for the ProVision DVR Ranger to connect to
4. When you click to connect you will need to use password **doesitall**
5. Once connected go to the internet and type 192.168.1.254

This will allow you to change the settings on the in-cab display among other things through the DVR.